Ripper

Mechanical work tool 0-33 tonnes



Break up hard ground and surfaces efficiently

Use the ripper on the excavator to break through hard or frozen ground, remove rocks, tree roots or old pipes. It is an efficient attachment for structural demolition or preparing the ground before using a digging bucket, when conditions are too hard for normal excavation.

The design allows for optimal breakout force and the tooth on the ripper can easily be replaced.

Technical specification

Ripper	RP30	RP40	RP45	RP50	RP60	RP70
Bracket	S30	S40	S45	S50	S60	S70
Machine weight [ton]	0-2	2-6	6-13	6-13	13-18	18-33
Weight from [kg]	32	76	194	195	278	550
Length [mm]	485	623	906	906	1009	1261